


Sprinkler Head Cabinet

Central Sprinkler Company
451 North Cannon Avenue, Lansdale, Pennsylvania 19446



Product Description

Central Sprinkler Head Cabinets are constructed of a metal enclosure with a hinged cover designed to provide on-site storage of an emergency supply of sprinkler heads and a sprinkler head wrench.

NFPA 13 requires a representative number of each type of sprinkler head used in a sprinkler system to be stored in a cabinet on-site to allow for immediate removal and replacement of sprinklers which may have operated or become damaged.

Central Sprinkler Head Cabinets are manufactured of heavy gauge steel with knock-outs to accommodate either 1/2" or 3/4" N.P.T. threaded sprinkler heads and are painted an attractive red enamel. They are available in three (3), six (6) or twelve (12) head capacity.



Technical Data

Model: Sprinkler Head Cabinet

Style: 3, 6 or 12 head

Standard Finish: Red enamel

Mfgr. Source: Non-domestic

Capacity: 3 sprinkler heads
6 sprinkler heads
12 sprinkler heads

Dimensions:

3 head - 5" high x 7 1/2" long x 2 1/2" deep
6 head - 5" high x 14" long x 3 1/4" deep
12 head - 5" high x 14 3/4" long x 5" deep

Weight: 3 head - 1.5 lbs.
6 head - 2.3 lbs.
12 head - 4 lbs.



3, 6 & 12 Head Sprinkler Head Cabinet



Installation

Central's Sprinkler Head Cabinet is designed with two $\frac{3}{16}$ " diameter holes for wall mounting or direct attachment to the system riser with a strap-type hanger. The Cabinet should be installed at or near the system control valve and must be stocked with an adequate supply of spare sprinklers and a sprinkler wrench.

The stock of spare sprinklers should include sprinklers of each type and temperature rating as are installed in the sprinkler system, in the following quantities:

Sprinklers In System	Spare Sprinklers Required
under 300	6
300-1000	12
over 1000	24


The Cabinets are designed to accept both $\frac{1}{2}$ " and $\frac{3}{4}$ " N.P.T. threaded sprinklers. For $\frac{1}{2}$ " N.P.T. sprinklers, leave the removable knockout in the hole. For $\frac{3}{4}$ " N.P.T. sprinklers, insert a screwdriver blade from the front top of the shelf and under the near bottom part of the knockout annular ring. Press the screwdriver handle down to remove the knockout ring. The hole, with the knockout ring removed, will accept a $\frac{3}{4}$ " N.P.T. sprinkler.



Care & Maintenance

The Cabinet, wrench, and stock of spare sprinklers should be inspected at least quarterly. The following items should be checked:

1. The Cabinet should be readily accessible, and not exposed to a corrosive atmosphere or temperatures in excess of 100°F/38°C.
2. The stock of spare sprinklers should include an adequate number of each type and temperature rating.
3. The stock of sprinklers must be in good condition.
4. A sprinkler wrench of the appropriate type must be included in the Cabinet.



Ordering Information

When placing an order, indicate the full product name. Please specify the quantity, model, style, capacity, and size.

Sprinklers, wrenches, and hardware for hanging are not supplied with the Cabinet. They must be ordered separately.

Availability and Service: Central sprinklers, accessories, and other products are available throughout the U.S. and Canada, and internationally through a network of Central Sprinkler distribution centers. You may write directly to Central Sprinkler Company, or call (215) 362-0700 for the distributor nearest you.

Guarantee: Central Sprinkler Company will repair and/or replace any products found to be defective in material or workmanship within a period of one year from date of shipment. Please refer to the current Price List for further details of the warranty.

Conversion Table:

1 inch = 25.400 mm
1 foot = 0.3048 M
1 pound = 0.4536 kg

Conversions are approximate.



Central Sprinkler Company

451 North Cannon Avenue, Lansdale, PA 19446
Phone (215) 362-0700
FAX (215) 362-5385